

Fitting a shirt into your sports shirt frame

To make things easy everything is inserted or removed from the back, with the case face down.

now you have the display frame you can see how it all goes together.

Simply turn the scroll clips away from the backing board (Brown Board) and take out the white foamcore board.

1. Arrange the shirt onto the white foamcore backing board



2. Pin the shirt into the EDGES (Sides) of the foamcore



3. Fold the rest of the shirt around the back



Remove the plastic protective layer from the glazing on BOTH SIDES (This simply peels off. Leave this till you are finished, so that it remains clean, and try to guard against static attracting dust and bits and pieces to it as you remove the protective layers.

4. Now put the white board you pinned your shirt onto back into the frame, replace the backing board, and turn the scroll clips to secure the backing.

Hanging: We have enclosed two suitable D-Ring hanging fixtures for the weight of this item, plus screws so you can fix these in and hang the display frame either way. We highly recommend that you hang this on TWO secure fittings, due to the weight of the item. We cannot pre-fit these, as we do not know which way up you will want to hang the frame. Fit these last! The cord supplied is rated to over 100lb/45kg.

Any problems please don't hesitate to contact us!

Moonshine Framing
1 High Street, Penzance, TR18 2SX
Tel: 01736 330887
www.frames.uk.com